Instructions:

Wipe the area clean, place the tape over the crack or joint, press firmly on the outside of the damaged area, cut to size, paint directly.

Options: skim for a smooth surface or texture for a textured surface.

It is best to install the tape when crack is closed.

Enjugue el área limpia, coloca la cinta sobre la grieta o la coyuntura, prensa firmemente por fuera del área dañada, el corte para calibrar, pintar directamente.

Las opciones: espuma para una superficie o la textura lisas para una superficie con textura.

*Cut to the desired length.
*Painting with a roller is recommended.
*Make sure that the area to be repaired is clean and dry.
*Remove backing, while applying the tape.
*Press firmly outside of the damaged area while applying.
*The crack to be covered must be even(not higher on one side)
*For long irregular cracks, run the tape end to end slightly overlapping.
*For a perfect match on smooth walls..skim the edges of the tape.
*For textured walls, you can blend with a can of spray texture.
*On corners..crease in the desired direction prior to removing the backing.
*Can be used to repair the edges of mis-cut outlets.
*Can be used to repair smaller holes as well.

On large cracks install the tape when the crack is closed

Checkout our demonstration videos online at:
www.youtube.com/StepSavers

If the your crack opens & closes from a narrow crack to a wider crack, then back. We strongly recommend that you install the tape when the crack is closed (in its tightest position). The tape is designed to stretch with the crack, then return. However if you install when the crack is open then it closes, it will push out, then go flat when it opens again. You can install on hairline cracks, and non-moving (static) cracks anytime.

Edges can be skimmed on smooth flat walls for a perfect match. For Indoor use only.